

M200 Power Supply Port Cover Installation Instructions

Swagelok

Kit contents:

Port cover



#6-32 x 1/2 Screws (2)



Torx driver



Ordering numbers: SWS-M200-CS-PORT-CVR 188-SCPTP-138-32-500-BN SWS-M200-T-TORX15

1. Remove the two **screws** from the left side of power supply using the Torx driver and discard screws.



2. Place port cover over ports, lining up the screw holes and recesses on the port cover with the screw holes and serial monitor and USB connections on the power supply.



3. Install the new screws and tighten until screws and port cover are flush. Turn screws 1/16 turn past flush.
Note: If the cover plate is removed, reinstall the screws on the power supply.

